



SOCVW-21

VOLKSWAGEN

2012 - 2014 Beetle
 2009 - 2014 CC
 2006 - 2012 Eos
 2002 - 2014 Golf
 2006 - 2014 GTI
 2002 - 2014 Jetta
 2002 - 2014 Passat
 2006 - 2011 Rabbit
 2009 - 2014 Tiguan
 2004 - 2010 Touareg

RADIO REPLACEMENT FOR SELECT VOLKSWAGEN VEHICLES 2002-UP

We recommend reading this installation guide first before starting any work. Following these instructions from "Start" to "Finish" will ensure a smooth and hassle free installation. We offer telephone support M-F 9:00 AM - 5:00 PM PDT at 1 (855) 822-1348. We are here to help.

PARTS INCLUDED:

- (1) Interface Module
- (2) VW Harness
- (1) Instruction Sheet

PRECAUTIONS:

- Remove the negative side of the battery to avoid any short circuits during the installation.
- Do not install the interface near any major components or near the HVAC system. This may cause damage or overheating to the vehicle.

PRELIMINARY:

Please read the entire manual before installing this interface.

Before installing this interface please review the options before removing the factory radio. Some options may need to be adjusted prior to removing the factory radio.

IMPORTANT:

DO NOT DISCONNECT THE AIRBAG CONNECTOR BEHIND THE DASH PANEL WHILE KEY IS IN THE IGNITION.

WIRING COLOR CODES

Black	= Ground
Red	= Accessory (2A Max)
Yellow	= Constant
Orange	= Illumination (100mA Max)
Blue/White	= Amplifier Turn-On
White	= Left Front (+)
White/Black	= Left Front (-)
Gray	= Right Front (+)
Gray/Black	= Right Front (-)
Green	= Left Rear (+)
Green/Black	= Left Rear (-)
Purple	= Right Rear (+)
Purple/Black	= Right Rear (-)
Purple/White	= VSS
Red/White	= Reverse (100mA Max)

IMPORTANT NOTES:

1. Driver information display will show the last information that was shown prior to removing the factory radio.
2. This interface does not retain the factory Bluetooth or Sirius SAT radio.
3. The radio is designed to shut off when the key is removed.

2010 and Up vehicles with a premium sound system do not retain the RAP feature


OVERVIEW OF INSTALLATION

MATCH LOOSE WIRES TO AFTERMARKET RADIO



TROUBLESHOOTING

LED LIGHT	LED MODULE FEEDBACK
Solid blue	CAN recognized
Flashing blue	CAN not recognized
Solid red	Module providing 12V ACC
Red off	12V ACC OFF



INSTALLATION TIPS

1. Test the radio for power, turn the key to the "ON" position and confirm that the new radio is getting power. If no power, please revise your wiring connections with multi-meter, available at your local car audio dealer.
2. Test the installation by turning the vehicle to the "ON" position, then back to the "OFF" position. Remove the key and confirm that the radio shuts off.

USING A RELAY

The module has been rated for up to **2A** max of output. For applications demanding a continuous output of 3A or more, we recommend using a standard BOSCH (SPDT) relay. See your local car audio specialist.

Below is a diagram on how to install the BOSCH relay.

