



PRODUCT FEATURES:

- Retains Steering Wheel Controls via built-in, pre-programmed interface.
- Retains VR Command (Voice Recognition) function on select OEM steering wheel controls to activate CarPlay and Android Auto compatible devices.
- Also works on the new generation Sony Radio with CarPlay function.

PARTS INCLUDED:







SWR-A Harness



SWC Cable

VEHICLE APPLICATIONS:

1991-2006	BMW	2003-2013	Honda	2005-2012	Nissan
2003-2012	Ford	2006-2014	Kia	2007-2015	Subaru
2006-2018	Hyundai	2003-2015	Mazda	2003-2018	Toyota

SUPPORTED RADIOS:

Alpine Dual JVC Power Acoustik

Boss Fahrenheit Kenwood Sony

Clarion Jensen Pioneer Soundstream

and Most off brand Radios

INSTALLATION DIAGRAM:

LED TROUBLESHOOTING ON MODULE

	LED LIGHT		LED MODULE FEEDBACK		
	BLUE	LED OFF	NO POWER	CHECK VOLTAGE	
	RED LE	O FLASHES	WHEN PRESSING SWC BUTTONS		3.5MM SWC CABLE
	Ground ACC iBus SWC 1 SWC 2	Blad Red/Whi White/Red Orange/Blad Yellow/Blad	te ed ck	ON RADIO VEHICLE	Plug in the 3.5MM SWC cable to the 4-pin port on the module. See below for DIP switch settings. Cap or insulate if not being used 4-Pin Connector Insulate with tape if not being used
	Signal Return	Bla	ck —		



rev.081022



AFTERMARKET RADIO DIP SWITCH SETTINGS:

Radio	DIP Switch				
Brand	1	2	3	4	
Alpine	OFF	OFF	OFF	OFF	
Boss	OFF	OFF	ON	ON	
Clarion	OFF	ON	ON	OFF	
Dual	OFF	OFF	ON	ON	
Fahrenheit	OFF	OFF	ON	ON	
Jensen	OFF	OFF	ON	ON	
JVC	OFF	ON	OFF	ON	
Kenwood	OFF	ON	ON	ON	
New Sony	OFF	OFF	ON	OFF	
Old Sony	OFF	ON	OFF	OFF	
Pioneer	OFF	OFF	ON	ON	
Power Acoustik	OFF	OFF	ON	ON	
Soundstream	OFF	OFF	ON	ON	
Most off brand radios	OFF	OFF	ON	ON	

NOTE: For Blaupunkt, Dual, Farenheit, Power Acoustik, Soundstream, and most off-brand radios, check the aftermarket radio's manual to see if the SWC buttons need to be programmed.

VEHICLE WIRING CONNECTIONS AND DIP SWITCH SETTINGS:

For vehicle specific wiring diagram and connections, please visit: www.cruxinterfacing.com/wiring or click on the QR code.





rev.081022