



Radio Replacement with Steering Wheel Control Retention for Select SUBARU Vehicles 2008 - 2015


## **PRODUCT FEATURES:**

- Retains factory features in select Subaru vehicles while functioning with an aftermarket radio.
- Pre-programmed to retain factory Steering Wheel Controls.

#### **PARTS INCLUDED:**



## **INSTALLATION DIAGRAM:**



Connect BROWN to BROWN wire.

\*\*\*See special note on 2010 & 2011 Forester, Legacy and Outback connection on page 2\*\*\*



rev.040721






Radio Replacement with Steering Wheel Control Retention for Select SUBARU Vehicles 2008 - 2015

# **DIP SWITCH SETTINGS:**

## **AFTERMARKET RADIO DIP SWITCH SETTINGS:**

RADIO BRAND:	DIP:	1	2	3	4
Atoto, Dual, Farenheit, Jensen, Pioneer		OFF	OFF	ON	ON
Power Acoustik, Soundstream		OFF	OFF	ON	ON
Blaupunkt, Most off-brand Radios		OFF	OFF	ON	ON
Alpine		OFF	OFF	OFF	OFF
Clarion		OFF	ON	ON	OFF
Kenwood		OFF	ON	ON	ON
JVC		OFF	ON	OFF	ON
Boss, Old Sony		OFF	ON	OFF	OFF
New Sony		OFF	OFF	ON	OFF




**NOTE:** For Atoto, Blaupunkt, Dual, Farenheit, Power Acoustik, Soundstream, and most off-brand radios, check the aftermarket radio's manual to see if the SWC buttons need to be programmed.

**UPDATE:** For Dual model number XDCP97BT, set DIP switches to OFF ON OFF OFF.

## SUBARU STEERING WHEEL CONTROL DIP SWITCH SETTING:

STEERING WHEEL CONTROL DIP SWITCHES ARE TO BE SET IN ACCORDANCE WITH THE ORIGINALLY REMOVED FACTORY RADIO:

DIP:	5	6	7	8
Panasonic made Radio	ON	OFF	ON	OFF
Clarion made Radio*	ON	OFF	ON	OFF
	OFF			
Fujitsu Ten made Radio	OFF	ON	OFF	l on l







Original radio manufacturer information can be found on the label on top of the radio.

## **3.5MM SWC CABLE**

Plug in the 3.5MM to 4-Pin SWC cable to the SWC module.

NOTE: Insulate the Blue/Yellow wire or 3.5mm plug if not being used.

# SPECIAL NOTE ON 2010 & 2011 FORESTER, LEGACY and OUTBACK:

For the year model Subaru vehicles listed above, check the factory radio harness if it has a GREEN/YELLOW wire across the BROWN wire on the SWRSU-38B harness (see diagram A). If it has a GREEN/YELLOW wire disconnect the BROWN wire 2 pin connector (diagram B). Set DIP switches 5 to 8 to: **ON OFF ON OFF**.




diagram A




diagram B



2 of 3

rev.040721

stFor steering wheels without pickup and hangup phone buttons.

<sup>\*\*</sup>For steering wheels with pickup and hang up phone buttons.







# **INSTALLATION INSTRUCTIONS:**



1. We recommend putting tape around the radio bezel to protect the dashboard from being scratched.



2. Use a plastic pry bar and carefully lift the radio bezel going all the way around it. Having a second pry bar would help.



3. Once you have lifted the radio bezel, carefully pull it out. Again, slowly going all the way around it using your hands.



4. There are 4 screws holding the radio.



5. Pull out the radios and unplug the connectors.



6. Plug in the SWRSU-38B T-harness to the vehicle harness and hide the module in the radio cavity.

- 7. Use the necessary dash kit (not included) to complete the installation. Connect the aftermarket radio wires to the SWRSU-38B T-harness.
- 8. Test the radio for functionality before installing the new radio into the dash. Carefully reinstall the radio bezel.

# **VEHICLE APPLICATIONS:**

## **SUBARU**

2009-2015	Forester*
2008-2014	Impreza (WRX)
2010-2014	Legacy*
2010-2014	Outback*
2013-2014	XV Crosstrek



Subaru Outback Radio

<sup>\*</sup>See special note on 2010 and 2011 Forester, Legacy and Outback on page 2.



3 of 3

rev.040721