

PRODUCT FEATURES:

- OEM style camera pods for the left and right side mirrors.
- Includes adjustable angle cameras.

PARTS INCLUDED:



INSTALLATION PROCEDURE:



1. Remove the side mirrors by first removing the corner sail panels. Unplug the mirror harness.

2. Remove the OEM side mirror camera cover and run the CSV-TUN camera cable through the harness hole.



3. Remove the screws on the interior door handle and door pull.

4. Remove the window controls and unhook the door panel by pulling it upward.



5. Fish the camera cable through the wiring boot for a clean look.

6. Tuck in the camera cable inside the cavity and snap in the CSV-TUN side mirror cover with camera.

VEHICLE APPLICATIONS:

TOYOTA

2016 - 2018 Tundra (3rd Generation)

