



Radio Replacement with OnStar, SWC Retention, & Double DIN Dash Kit for GM Class II Vehicles 2003 - 2013

### **PRODUCT FEATURES:**

- Retains factory features in select GM Class II Data Bus vehicles while functioning with an aftermarket radio.
- Pre-programmed to retain factory Steering Wheel Controls.
- Supports Bose, non-Bose and Y-91 audio systems.
- Retains OnStar and chime functions.
- EIA color coded wiring for easy installation.
- Includes Double Din Dash kit

#### **NOTES:**

- 1. The Front and Rear fading are not retained on Y-91 Bose System.
- 2. The OnStar volume output is defaulted to low gain.
- 3. Does not retain rear seat volume controls.

#### **PARTS INCLUDED:**











DOUBLE DIN DASH KIT

DKGM-15 Module


**DKGM-15 Harness** 

**SWC Cable** 

Antenna Adapter


### **INSTALLATION DIAGRAM:**






24-Pin Connector

3.5mm port










Green

Green/Black



8-Pin Connector € ← Chime Volume Adjustment

> 3.5MM SWC CABLE Plug in the 3.5MM SWC cable to the 4-pin port on the module. See "DIP SWITCH SETTINGS" section.



1 of 4

JVC/Kenwood (Blue / Yellow)





Radio Replacement with OnStar, SWC Retention, & Double DIN Dash kit for GM Class II Vehicles 2003 - 2013

# **DIP SWITCH SETTINGS:**

RADIO BRAND:	DIP#:	1	2	3	4	
Atoto, Dual, Fahrenheit, Jensen,		OFF	OFF	ON	ON	
Pioneer, Power Acoustik, Soundstream		OFF	OFF	ON	ON	l
Blaupunkt, Most off-brand Radio		OFF	OFF	ON	ON	l
Alpine		OFF	OFF	OFF	OFF	l
Clarion		OFF	ON	ON	OFF	l
Kenwood		OFF	ON	ON	ON	l
JVC		OFF	ON	OFF	ON	l
Boss, Old Sony		OFF	ON	OFF	OFF	l
New Sony		OFF	OFF	ON	OFF	

**SWC MODULE DIP SWITCH** 



2 3 4

NOTE: For Atoto, Blaupunkt, Dual, Farenheit, Power Acoustik, Soundstream, and most off-brand radios, check the aftermarket radio's manual to see if the SWC buttons need to be programmed.

### 3.5MM SWC CABLE

Plug in the 3.5MM to 4-Pin SWC cable to the SWC module or use the Blue/Yellow wire for JVC and Kenwood.

For aftermarket radios that have wires for SWC connections, cut off the 3.5mm plug on the Crux SWC Cable and connect the SWC wires as follows:


Note that there are some radios that only have SWC1 and SWC2, in this case "shield" does not need to be connected.



### **SELECTING THE AUDIO SYSTEM:**

If the vehicle is equipped with an amplified audio system, the DKGM-15 has a built-in audio level adaptor that outputs the proper audio level from the aftermarket radio to the factory amplifier. To use this feature, plug in the male 8-pin connector on the DKGM-15 harness to the GRAY female 8-pin connector on the DKGM-15 module. The module is also labeled "Bose" and "Non Bose" to avoid confusion. (see picture below)

If the vehicle is NOT equipped with a factory amplified system, plug in the male 8-pin connector to the BLACK female 8-pin on the DKGM-15 module.



## **CHIME VOLUME ADJUSTMENT:**

The DKGM-15 has a potentiometer to adjust the chime volume. It is set at half way by default. To adjust the volume, simply use a suitable screw driver and turn the potentiometer clockwise to increase the volume and counter-clockwise to decrease the volume.



Adjustment








Radio Replacement with OnStar, SWC Retention, & Double DIN Dash Kit for GM Class II Vehicles 2003 - 2013

## **DASH KIT INSTALLATION:**


A Double DIN radio replacement dash kit is included in the kit to make the installation quick and easy.

Please make sure that you have all the parts shown below.


- (1) Main trim ring
- (1) Left ISO mounting bracket
- (1) Right ISO mounting bracket



### **Dash Kit Assembly**



For Some Cadillac installation, see diagram below:







# **ONSTAR VOLUME ADJUSTMENT:**

To adjust the OnStar volume, turn on OnStar and adjust the volume using the Steering Wheel Control volume

# **VEHICLE APPLICATIONS:**

BUICK		GMC		
2004-2005	Century	2004-2011	Canyon	
2005-2007	LaCrosse	2002-2009	Envoy	
2004-2007	Rainier	2003-2007	Savana	
2003-2007	Rendezvous	2003-2006	Sierra	
2005-2007	Terraza	2007	Sierra Classic	
		2003-2006	Yukon	
CADILLAC				
2004-2006	Escalade	HUMMER		
		2003-2007	H2	
CHEVROLET		2005-2010	H3	
2003-2006	Avalanche			
2000-2005	Cavalier	ISUZU		
2004-2013	Colorado	2003-2008	Ascender	
2004-2007	Express			
2000-2005	Impala	OLDSMOBILE		
2001-2003	Malibu	2001-2004	Alero	
2000-2005	Monte Carlo	2002-2004	Bravada	
2003-2004	S-10	2000-2004	Silhouette	
2003-2006	Silverado			
2007	Silverado Classic	PONTIAC		
2003-2006	SSR	2001-2005	Aztec	
2003-2006	Suburban	2001-2005	Grand Am	
2003-2006	Tahoe	2004-2008	<b>Grand Prix</b>	
2002-2009	Trailblazer	2000-2006	Montana	
2005-2008	Uplander	2000-2005	Sunfire	
2003-2005	Venture			
		SAAB		
		2005-2008	9-7X	
		SATURN		
		2005-2007	Relay	

# NOTE:

- Does not retain rear seat volume controls.

