


## How to Eliminate Factory Amp Pop Using Low-Level Outputs for Aftermarket Radios

## **INSTALLATION DIAGRAM:**



CRUX
Interface Rear Speakers LOC-2 Aftermarket Radio
(SOOCR-26 or SWRCR-59) (Or any other brand )

**Note:** Please use this QR code to view a video with more information on this subject.



