

SWRFD-60T

Radio Replacement with Steering Wheel Control Retention for Select 2020 and Up Ford Vehicles

PRODUCT FEATURES:

- Retains Factory Features in Select Ford Vehicles.
- Retains Factory Steering Wheel Controls via Built-in Pre-programmed Interface.
- Made for Non Amplified Vehicles.
- Provides Accessory Power (2A max).
- Provides Illumination Output.
- Provides Reverse Signal.

PARTS INCLUDED:







SWRFD-60T HARNESS




SWC Cables



Univeral Radio Key A Key B SWC

INSTALLATION DIAGRAM:



1 of 3

rev.072925



SWRFD-60T

Radio Replacement with Steering Wheel Control Retention for Select 2020 and Up Ford Vehicles

DIP SWITCH SETTINGS:

AFTERMARKET RADIO DIP SWITCH SETTINGS:

| RADIO BRAND: | DIP#: | 1 | 2 | 3 |
|---|-------|-----|-----|-----|
| Atoto, Dual, Fahrenheit, Jensen, Nakamichi, | | OFF | ON | ON |
| Pioneer, Power Acoustik, Soundstream | | OFF | ON | ON |
| Blaupunkt, Most off-brand Radio | | OFF | ON | ON |
| Alpine | | OFF | OFF | OFF |
| Clarion | | ON | ON | OFF |
| Kenwood | | ON | ON | ON |
| JVC | | ON | OFF | ON |
| Boss, Old Sony | | ON | OFF | OFF |
| New Sony (with CarPlay) | | OFF | ON | OFF |

SWC MODULE DIP SWITCH



1 2 3

Located internally Need to take plastic Casing off module

SWC Troubleshoot option

If Steering Wheel Controls don't work or work properly please switch internal dip switch from 3v3 to 5v as shown in picture above.


NOTE: For Atoto, Blaupunkt, Dual, Farenheit, Nakamichi, Power Acoustik, Soundstream, and most off-brand radios, check the aftermarket radio's manual to see if the SWC buttons need to be programmed.

3.5MM SWC CABLE

Plug in the 3.5MM to 4-Pin SWC cable to the SWC module or use the Blue/White wire for JVC and Kenwood.

For aftermarket radios that have wires for SWC connections, cut off the 3.5mm plug on the Crux SWC Cable (option B) and connect the SWC wires as follows:

Note that there are some radios that only have SWC1 and SWC2, in this case "shield" does not need to be connected.



RED to SWC Key 1 WHITE to SWC Key 2 SHIELD to SWC Ground

Universal Radios BROWN to SWC Key 1 BROWN/WHITE to SWC Key 2

VEHICLE APPLICATIONS:

FORD

2021 - Up E Series

2020 - Up Eco Sport

2020 - Up Escape

2020 - Up F250/F350/F450/F550

2020 - Up Transit

2020 - Up Transit Connect

NOTE:

Does not retain Sync.



2 of 3

rev.072925




SWRFD-60T


Radio Replacement with Steering Wheel Control Retention for Select 2020 and Up Ford Vehicles

STEERING WHEEL CONTROL TROUBLE SHOOTING:

Note: Identify Alpine SWC learning radios by checking for three SWC cables and a SWC learn menu, instead of a 3.5mm SWC input.

If Interface has one SWR-100 Cable included If Interface has two SWR Cables included 1 - Identify appropriate SWC adapter cable. 1 - Find the included SWC adapter cable. Do not use cable with Blue / Yellow wire. 2 - Prepare the SWC Cable: Cut the SWC cable. You will find a red wire, a white wire, and a ground (shield) wire inside. 3 - Adjust the Module Settings: Set the module to the Pioneer dip switch setting. This configures the module to communicate correctly with the Alpine radio. SWC MODULE On Alpine iLX series radios use Pioneer settings | OFF 4 - Configure the Alpine Radio: On your Alpine radio, select the setting that includes "Without adapter" for SWC. This ensures the radio will recognize the steering wheel controls. Select "SWC Adapter" Select the setting "Without Adapter" 5 - Connect the Wires: Connect both the SWC1 and SWC2 wires from aftermarket radio to the red wire from our SWC cable. Connect the SWC ground wire to the shield (ground) wire of our SWC cable. These steps should enable the steering wheel controls on your Alpine iLX series radio.





6. Program the SWC: Navigate to the SWC settings on your Alpine radio to assign and test each control function.

3 of 3