

PRODUCT FEATURES:

- Retains factory features in select Honda vehicles while functioning with an aftermarket radio.
- Pre-programmed to retain factory Steering Wheel Controls.
- Provides navigational outputs: Reverse, Illumination, Parking Brake, Vehicle Speed Sense & Lanewatch Camera Outputs.
- Retains factory Multi-Angle Rear View Camera & Lanewatch Camera, & Auxiliary Input.
- Includes antenna adapter & USB retention cable.


NOTES:

1. Supports both Amplified & Non-amplified vehicles.
2. Does not retain Rear Seat Entertainment system (RSE).
3. Includes Crux Video Switcher to Lanewatch and rear view camera retention.
3. If vehicle does not have Lanewatch camera interface can still be used.

PARTS INCLUDED:



INSTALLATION DIAGRAM FOR AMPLIFIED VEHICLES WITH LANE WATCH CAMERA:




*Connect the white subwoofer RCA jack to the subwoofer output on the aftermarket radio.


Note: If the aftermarket radio has limited RCA outputs, a 1 male to 2 female (1M2F) RCA splitter may be required.



INSTALLATION DIAGRAM FOR NON-AMPLIFIED VEHICLES WITH LANE WATCH CAMERA:



* For Non-Amplified systems please cut RCA , and mate colored wires to the appropriate aftermarket radio speaker wires



ALTERNATIVE ACCESSORY POWER TROUBLE SHOOTING:



Note: If you are experiencing issues with accessory power from the module, connect the provided alternative power wire to the CRUX connector and then to the aftermarket radio



HARNESS VIEW


For Vehicles with STANDARD KEY

If your vehicle uses a regular key, connect the red accessory wire using the 2-pin female Molex connector to the matching 2-pin male Molex connector as shown in the diagram, then connect the wire to the aftermarket radio.



For Vehicles with PUSH START ignition

If your vehicle has a push-start button, connect the red/black Ignition ACC wire using the 2-pin female Molex connector to the matching 2-pin male Molex connector as shown in the diagram, then connect the wire to the aftermarket radio.



DIP SWITCH SETTINGS:

AFTERMARKET RADIO DIP SWITCH SETTINGS:

RADIO BRAND:	DIP:	1	2	3	4
Atoto, Dual, Farenheit, Jensen, Pioneer		OFF	OFF	ON	ON
Power Acoustik, Soundstream		OFF	OFF	ON	ON
Blaupunkt, Most off-brand Radios		OFF	OFF	ON	ON
Alpine		OFF	OFF	OFF	OFF
Clarion		OFF	ON	ON	OFF
Kenwood		OFF	ON	ON	ON
JVC		OFF	ON	OFF	ON
Boss, Old Sony		OFF	ON	OFF	OFF
New Sony		OFF	OFF	ON	OFF
SWC Learning Radios*		ON	OFF	OFF	ON

SWC MODULE DIP SWITCH



NOTE:
DIP Switches
5-6 are not used

SWC Troubleshoot option



Located internally
Need to take plastic
Casing off module

- If Steering Wheel Controls don't work or work properly please switch internal dip switch from 3v3 to 5v as shown in picture above.

NOTE: For Atoto, Blaupunkt, Dual, Farenheit, Nakamichi, Power Acoustik, Soundstream, and most off-brand radios, check the aftermarket radio's manual to see if the SWC buttons need to be programmed.

*For SWC Learning Radios specific steps are required please scan the QR code on the right.

4-PIN SWC CABLE

Use the proper 3.5MM to 4-Pin SWC cable for the aftermarket radio you are using.

OPTION A is used for ALPINE, CLARION. Use the Blue/Yellow wire for JVC and KENWOOD units.
OPTION B is used for ATOTO, BLAUPUNKT, BOSS, DUAL, FARENHEIT, JENSEN, POWER ACOUSTIK, PIONEER, SONY, SOUNDSTREAM and Most Off-Brand Radios.

NOTE: Cap or insulate the 3.5mm plug or Blue/Yellow wire if not being used.

For aftermarket radios that have wires for SWC connections, cut off the 3.5mm plug on the Crux SWC Cable (option B) and connect the SWC wires as follows:



Note that there are some radios that only have SWC1 and SWC2, in this case "shield" does not need to be connected.


TROUBLE SHOOTING FOR SWC LEARNING RADIOS



HOW TO DETERMINE IF THE VEHICLE HAS ANALOG SWC:

Analog Steering Wheel Control (SWC) signal vehicles will have wires populated and line up to the Blue/Red wire on the 24-Pin Crux connector. If this applies for your vehicle, Connect the 2 pin Blue/Red male & female connectors.

Example: 2016 HR-V w/ Display Audio Type 7in and Audio-NAV.



VEHICLE APPLICATIONS:

2012- 2015 CIVIC HF/LX/EX/EX-L
2012- 2015 CIVIC Si/Hybrid/Type-R
2012- 2015 CIVIC EX-L/Si w/ NAV
2012- 2015 CIVIC Hybrid/w/ NAV
2015- 2015 CIVIC Touring w/ NAV
2015- 2016 CRV LX (w/ 5" screen)

2015- 2016 CRV EX/EX-L/Touring (w/ 7" screen)
2012- 2016 CRV EX-L w/ NAV (w/ 7" screen)
2015- 2017 FIT EX (w/ 7" screen)
2015- 2017 FIT EX-L (w/ 7" screen)
2016- 2020 HRV EX/EX-L (w/ 7" screen)
2016- 2020 HRV EX-L w/ Nav (w/ 7" screen)

NOTE: Auxiliary input cable will in limited applications, will not work w/ Display audio and NAV w/ Display Audio System
Does not support base Honda Civic DX trim w/o SWC



MULTI-ANGLE REAR VIEW CAMERA

The Crux SWRHN-62CV retains the factory Multi-Angle Rearview Camera functionality. Use the factory source button on the steering to switch between the available camera views. Follow steps below.



Place vehicle in reverse for Default camera view




For wide angle view press source button for 1 second



For top down camera view press source button for 1 second






LANE WATCH CAMERA RETENTION INSTALLATION:



STEERING WHEEL CONTROL TROUBLE SHOOTING:

Note: Identify Alpine SWC learning radios by checking for three SWC cables and a SWC learn menu, instead of a 3.5mm SWC input.

If Interface has one SWR-100 Cable included	If Interface has two SWR Cables included
1 - Find the included SWC adapter cable.  2 - Prepare the SWC Cable: Cut the SWC cable. You will find a red wire, a white wire, and a ground (shield) wire inside.  3 - Adjust the Module Settings: Set the module to the Pioneer dip switch setting. This configures the module to communicate correctly with the Alpine radio. 4 - Configure the Alpine Radio: On your Alpine radio, select the setting "Without an adapter" for SWC. This ensures the radio will recognize the steering wheel controls. 5 - Connect the Wires: Connect both the SWC1 and SWC2 wires from aftermarket radio to the red wire from our SWC cable. Connect the SWC ground wire to the shield (ground) wire of our SWC cable. These steps should enable the steering wheel controls on your Alpine iLX series radio.  NOTE: White wire not used 6. Program the SWC: Navigate to the SWC settings on your Alpine radio to assign and test each control function.	1 - Identify appropriate SWC adapter cable. Do not use cable with Blue / Yellow wire.    NOTE: White wire not used

2012-2016 Honda Civic/CRV With factory Nav SWC bluetooth & CAN connections:


In 2012–2016 vehicles with factory navigation, hardwired connections are required due to the use of a different connector and alternate wire locations for key systems. These include MS-CAN, steering wheel controls (SWC), subwoofer, multi-view camera (Multi RVC), and rear view camera.

For Detailed instructions please use this QR code



SWC BLUETOOTH TROUBLE SHOOTING (Continued):

CRV 7" Screen



NOTE: 2015 Honda CR-V SWC BT, bluetooth handsfree Link Control 32 pin connector is located behind the Gear shift

FIT 5" & 7" Screen

